



RAINSCREEN ARROWHEAD PANEL SIZE GUIDE		
FO = FRAME OPENING FINISHED PANEL SIZE = FO + 3/16"	SO = SILL OPENING FINISHED PANEL SIZE = SO	CO = CORNER OPENING FINISHED PANEL SIZE = CO + PD + 1/16" PD = PANEL DEPTH = 1 13/16"
SIZES ARE FOR UP TO 10' LONG PANELS @ 1/8" IN 10' @ <90°F THERMAL EXPANSION. FOR LONGER PANELS OR HIGH TEMPERATURE INCREASES MODIFY FORMULA ACCORDINGLY.		

